


38 732 000 SKATE COSMOPOLITAN FLUSH PLATE



SPARE PARTS, February 2010 – now

1: Top plate with push button (Order-nr. 42371000)

2: Screw (Order-nr. 6636200M)

3: Frame (Order-nr. 43207000)

4: Fixing set (Order-nr. 4308500M)*

* Optional accessories